

# Using your FLOE trailer

## Securing The Load

### QUICK-LOOP™ INSTALLATION

Lubricate the threads of the bolt with Anti-seize. Insert the Quick Loop assembly into the Versa-Track. Rotate the cam until the insert catches in the Versa-Track. While pulling up on the Quick Loop, tighten until insert stays engaged with slot. Slide the Quick Loop to the desired location and finish tightening the bolt. Quick Loops should be installed so that the pull is as close to perpendicular as possible.



### CAUTION



As with any tie-down system, the ultimate responsibility for ensuring that the load is adequately secured lies with the driver. At a minimum, FLOE recommends the use of a properly tensioned tie-down bar and a means to secure the rear of the snowmobile (as shown in Figs. 11 & 12). You may choose to do more or less, based on road conditions and your specific situation. Always use discretion when determining load-securing measures, and periodically check your load to ensure security is maintained.

